



The DNA of tech.™

## Tyvek Paper Alternative

For further information, please contact your regional Vishay office.

### CONTACT INFORMATION

#### Americas

Vishay EFI  
111 Gilbane Street  
-  
Warwick RI United States 02886  
Phone: +1- 401-691-4840  
Fax:  
Luigy.Johnson@vishay.com

#### Europe

Vishay Electronic GMBH  
Gehemrat-Rosenthal-STR,100  
-  
Selb Germany 95100  
Phone: +44-13 79 64 15 31  
Fax:  
richard.steel@vishay.com

#### Asia

Vishay Intertechnology Asia PTE  
37A Tampines St 92 #07-00  
-  
Singapore Singapore 528886  
Phone: +65-6788-6668  
Fax: +65-6788-0988  
leonard.tay@vishay.com

**Description of Change:** Due to the global supply chain disruptions, VEFI is taking the measure to add additional source of the packing material (Tyvek, Integris Part # H20-001D). New additional material will be IDPE sheet (Entegris Part # H20-001-0715).

**Reason for Change:** To avoid delays in the customer shipments due to increased lead time/unavailability from the Integris of the Tyvek Paper, Integris Part # H20-001D

**Expected Influence on Quality/Reliability/Performance:** None

**Part Numbers/Series/Families Affected:** Please see materials list on the succeeding page.

**Vishay Brand(S):** Vishay Electro-Films

**Time Schedule:**

Start Shipment Date: Friday May 22, 2026

**Sample Availability:** Immediate-IDPE sheet (Entegris Part # H20-001-0715)

**Product Identification:** 05/22/2026

**Qualification Data:** Attached

**This PCN is considered approved, without further notification, unless we receive specific customer concerns before Friday May 22, 2026 or as specified by contract.**

**Issued By:** Haley Guo, haley.guo@vishay.com



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

PWB311XXXXXWS	PWBXXXXXXKGNHT5	NET0130064WS	NET0190065WS	NET0290072WS
NET0400072WS	NET0410072WS	NET0340074WS	NET0430074WS	NET0520074WS
NET0640074WS	NET0660074WS	NET0730074WS	NET0930074WS	NET1000074WS
NET1010074WS	NET1020074WS	NET1030074WS	NET0360076WS	NET0370076WS
NET0380076WS	NET0058076WS	NET0770076WS	NET0780076WS	NET0790076WS
NET0800076WS	NET0420078WS	NET0300079WS	NET0310079WS	NET0130085WS
STR16912301FBEGSWS	NET0150087WS	NET0160087WS	NET0120088WS	NET0130101WS
NET0310102WS	NET0170106WS	NET0180106WS	NET0210106WS	NET0300123WS
NET0450123WS	NET0620123WS	NET0640123WS	NET0660123WS	NET0720123WS
NET0770123WS	NET0780123WS	NET0810123WS	NET0880123WS	NET0980123WS
NET1180123WS	NET1190123WS	NET1250123WS	STR10216121BBNSWS	STR10215111BBNSWS
NET0400124WS	NET0490124WS	NET0500124WS	NET0560124WS	NET0570124WS
NET0580124WS	NET0590124WS	NET0630124WS	NET0690124WS	NET0780124WS
NET0920124WS	NET1160124WS	NET1170124WS	NET0120129WS	NET0180142WS
NET0180144WS	NET0340144WS	NET0400144WS	NET0410144WS	NET0420144WS
NET0480144WS	NET0530144WS	NET0580144WS	NET0590144WS	NET0500145WS
NET0510145WS	NET0530145WS	NET0140149WS	NET0210149WS	NET0210155WS
NET0280155WS	NET0320155WS	NET0500155WS	NET0300170WS	NET0290171WS
NET0430171WS	NET0460171WS	NET0660171WS	NET0690171WS	NET0700171WS
NET0710171WS	NET0720171WS	NET0730171WS	NET0740171WS	NET0750171WS
NET0760171WS	NET0770171WS	NET0780171FW	NET0830171WS	NET084171WS
NET0420173WS	NET0440173WS	WNET016017600	NET0130177WS	NET048018900WS
NET0640189WS	NET0410191WS	NET046191WS	NET0530191WS	NET0310192WS
NET0370192WS	NET0380192WS	NET0350199WS	NET0470199WS	NET0530199WS
NET0940199WS	NET0960199WS	NET1040199WS	NET1060199WS	NET1140199WS
NET1180199WS	NET1220199WS	NET1260199WS	NET1270199WS	NET1480199WS
NET1490199WS	WNET159019900	NET1600199WS	NET2040199WS	NET2090199WS
NET2100199WS	NET2130199WS	NET2140199WS	NET2180199WS	STR51111302FBVKWS
NET2210199WS	NET2220199WS	NET2230199WS	NET2240199WS	NET2250199WS
NET2260199WS	NET0230200WS	NET0260200WS	NET0150205WS	NET0370206WS
NET0390206WS	NET0450206WS	NET0600206WS	NET0610206WS	NET0640206WS
NET0690206WS	NET1080206WS	NET1090206WS	NET1100206WS	NET1110206WS
NET0110209WS	NET0110210WS	NET0110211WS	NET0110212WS	NET0110214WS
NET0120217WS	NET0110220WS	NET0110221WS	NET0120224WS	NET0110228WS
NET0110229WS	NET0110230WS	NET0110238WS	NET0110242WS	NET0120248WS
NET0130248WS	NET0110250WS	NET0110255WS	NET0110257WS	NET0110258WS
NET0110259WS	NET0110260WS	NET0110261WS	NET0110262WS	NET0110271WS
NET0140278WS	STR16913881FBEGSWS	STR10213161BBNSWS	NET0110321WS	NET0150349WS
NET0260354WS	NET0130356WS	NET0380356WS	NET0390356WS	NET0140357WS
NET0130361WS	NET0130366WS	NET0150366WS	NET0240367WS	NET0250367WS
NET0280367WS	NET0290367WS	NET0300367WS	NET0170368WS	NET0130370WS
NET0140371WS	NET0150371WS	NET0150372WS	NET0110386WS	NET0110388WS
NET0110454WS	NET0120454WS	NET0130454WS	NET0150454WS	NET0140456WS
NET0110460WS	NET0120460WS	NET0110461WS	NET0110462WS	NET011046300WS
NET011046400WS	NET012046400WS	NET0110465WS	NET0110466WS	NET0120469WS
NET0110471WS	NET0410477WS	NET0420477WS	NET0580477WS	NET0590477WS
NET0600477WS	NET015050500WS	NET0120561WS	NET0120574WS	NET012058600
NET0120588WS	NET0380643WS	NET0400643WS	NET0500643WS	NET0520643WS
NET0590643WS	NET0600643WS	NET0120703WS	NET0120714WS	NET0120717WS
NET0110784WS	NET0130812WS	NET0200812WS	NET0220812WS	NET0230812WS
NET0240812WS	NET0250812WS	NET0150848WS	NET0160848WS	NET0170848WS
NET0190848WS	NET0220848WS	NET0260848WS	NET0270848WS	NET0160893WS
NET0170894WS	NET0210897WS	NET0130898WS	NET0120901WS	NET0150901WS
NET0160901WS	NET0170901WS	NET0180901WS	NET0190901WS	NET0200901WS
NET0160945WS	NET0280946WS	NET0540946WS	NET0570946WS	NET0590946WS
NET0640946WS	NET0650946WS	NET0660946WS	NET0670946WS	NET0680946WS



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

NET0690946WS	NET0700946WS	NET0730946WS	NET0280966WS	NET0110968WS
NET0110980WS	NET0311000WS	NET0391000WS	NET0411000WS	NET0121025WS
NET5091026WS	NET0181027WS	NET0191027WS	NET0241027WS	NET0261027WS
NET0111036WS	NET0111037WS	NET0151037WS	NET0161037WS	NET0171037WS
NET0211037WS	NET0221039WS	NET5041039WS	NET5061039WS	NET5071039WS
NET5081039WS	NET5141039WS	NET5251039WS	IGBACxxxxxJPHWS	IGBACxxxxxJPCWS
IGBACxxxxxMNCWS	IGBACxxxxxMPCWS	IGBADxxxxxOPHWS	IGBADxxxxxONHWS	NET0111081WS
NET0131082WS	NET0161108WS	NET0201108WS	NET0391108WS	NET04301108WS
NET04401108WS	NET04501108WS	NET0461108WS	NET0471108WS	NET0111110WS
NET0111111WS	NET0121111WS	NET0161121WS	NET0171121WS	NET5211121WS
NET5351121WS	NET5361121WS	NET0151122WS	NET0231122WS	NET0241122WS
NET0251122WS	NET0261122WS	NET0271122WS	NET0281122WS	NET0301122WS
NET0311122WS	NET0321122WS	NET0161123WS	NET0171123WS	NET0111124WS
NET0131124WS	NET0111158WS	NET0141159WS	NET0111216WS	NET0111218WS
NET0161236WS	NET0121247WS	NET0131266WS	NET0151266WS	NET0181268WS
NET0261268WS	NET0271268WS	NET0301268WS	NET0311268WS	NET0321268WS
NET0331268WS	NET0191269WS	NET0261269WS	NET0271269WS	NET0281269WS
NET0291269WS	NET0111279WS	NET0121279WS	NET0111296WS	NET0121296WS
NET0111297WS	NET012129700WS	NET013129700WS	NET0121298WS	NET0131298WS
NET0141298WS	NET0231329WS	NET0271329WS	NET0341329WS	NET0351329WS
NET0131340WS	NET0111346WS	NET0111347WS	NET0111348WS	NET012136400WS
NET0111365WS	NET0111376WS	NET0171378WS	NET0111395WS	NET0131395WS
NET0111399WS	NET0121399WS	NET0111400WS	NET0111422WS	NET0111423WS
NET0111425WS	NET0111426WS	NET0121426WS	NET0131426WS	NET0171426WS
NET0251426WS	NET0261426WS	NET0321426WS	NET0331426WS	NET0341426WS
NET0351426WS	NET0371426WS	NET0381426WS	NET0391426WS	NET0111429WS
NET0111449WS	NET0121468WS	NET0111480WS	NET0111483WS	NET0121483WS
NET0111487WS	NET0111488WS	NET0111506WS	NET0111507WS	NET0111508WS
NET0111509WS	NET0111514WS	NET0111516WS	NET01011533WS	NET01011534WS
NET0111554WS	NET0111566WS	NET0121573WS	NET0111578WS	NET0111579WS
NET0121579WS	NET0131579WS	NET0141579WS	NET0111581FW	NET0121581FW
NET0111582WS	NET0121582WS	NET0111584WT	NET0111586WS	NET0111589WS
NET01115900WS	NET0111591WS	NET01115920WS	NET0111593WS	STR25524022DDKJSWS
STR10021623DDKJSWS	NET0111597WS	RNET0111598	NET0111599WS	NET0111600WS
NET0111601WS	NET0111603WS	NET0111604WS	NET0111605WS	NET0111606WS
NET0111607WS	NET0111608WS	STR16912490FBEGSWS	VEFIRFHFKIT	VEFIIGBRKIT
VEFIHIPWKIT	VEFISMSZKIT	VEFISTRKIT	SPF106024-000	SPF106034-01C
SPF106787-010	SPF106788-000	SPF106789-010	SPF106792-000	SPF106975-000
SPF107046-X10	SPF107665-000	PSS107669-000	SPF107754-000	SPF108022-000
SPF108123-000	SPF108124-000	SPF108139-000	SPF108140-000	SPF108238-000
SPF108245-000	SPF108472-000	SPF108517-000	SPF108518-000	SPF108524-00A
SPF108529-000	SPF108648-000	SPF108742-000	SPF108849-000	SPF108896-000
SPF108898-000	SPF108918-00A	SPF108962-000	SPF108963-000	SPF108964-000
SPF108993-000	SPF109011-000	SPF109012-000	SPF109013-000	SPF109016-000
SPF109027-000	SPF109028-000	SPF109030-000	SPF109041-000	SPF109080-000
SPF109081-000	SPF109091-000	SPF109113-000	SPF109192-00A	SPF109206-00A
SPF109232-000	SPF109245-00A	SPF109484-00A	MTRxxxxxBRGNHWS	MTRxxxxxAMGGHWS
MTRxxxxxARGNHWS	MTRxxxxxARGGHWS	MTRxxxxxVGGHWS	MTRxxxxxBRGGHWS	MTRxxxxxAKGNHWS
MTRXXXXXBKGNHWS	MTRxxxxxBxANHWS	MTRxxxxxBRANHWS	MTRxxxxxBVGNHWS	MTRxxxxxAxGNHWS
MTRxxxxxBxGNHWS	MTRxxxxxAMANHWS	MTRxxxxxAMGNHWS	MTRxxxxxAKGGHWS	MTRxxxxxBKGGKWS
MTRxxxxxBKGGHWS	MTRxxxxxAKANHWS	MTRxxxxxBKANHWS	MTRxxxxxBKAGHWS	MTRxxxxxBKANKWS
MTRXXXXXACANHWS	MTRXXXXXBCANHWS	MTRXXXXXAEANHWS	MTRXXXXXBEANHWS	MTRXXXXXAKGNKWS
MTRxxxxxAKGGMWS	MTRxxxxxAMGGKWS	CLA08XXXXXyBMANHWS	CLX08XXXXXFEANKWS	CLA04XXXXXBEANHWS
CLA08XXXXXBEANHWS	CLA08xxxxxFKGGHWS	CLA08xxxxxGNKWS	CLA30156201BWS	CLA30220000FWS
MTTxxxxxMAGHWS	MTT075XXXXXWS	MTTxxxxxKGNHWS	MTTxxxxxKGGHWS	MTTxxxxxMGNHWS
MTTxxxxxMGGHWS	MTTxxxxxCGNHWS	MTTxxxxxCGGKWS	MTTxxxxxRANHWS	MTTXXXXXXGNHWS



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

MTT301XXXXXWS	MTT302XXXXXWS	PWAxxxxxxKANHWS	PWAxxxxxxCAHWS	PWAxxxxxxEAHWS
PWAxxxxxxCANHWS	PWAxxxxxxEANKWS	PWAxxxxxxVANHWS	PWAxxxxxxANHWS	PWAxxxxxxZAGHWS
PWAxxxxxxKANHXX	PWAxxxxxxKANKWS	PWAxxxxxxANKWS	PWAxxxxxxKGNHWS	PWAxxxxxxCGNHWS
PWAxxxxxxVGNHWS	PWAxxxxxxMGNHWS	PWAxxxxxxMANHWS	PWAxxxxxxEGNKWS	PWAxxxxxxCGNKWS
PWAxxxxxxKGNKWS	PWAxxxxxxVGNKWS	PWAxxxxxxZGNKWS	PWA256XXXXXWS	PWA257XXXXXWS
PWA300XXXXDWS	PWA301XXXXDWS	PWA302XXXXDWS	PWA303XXXXDWS	PWAxxxxxxKANHT5
CTN028xxxxxWS	CTNxxxxxxFKGANHWS	CTN154xxxxxWS	CTNXXXXXXFEGGNHWS	CTN205XXXXXWS
CTR066xxxxxWS	CTR095xxxxxWS	CTRxxxxxxFKJANHWS	CTRxxxxxxDEGANHWS	CTRxxxxxxFCGAGHWS
CTRxxxxxxFEGAGHWS	CTRxxxxxxVEGANKWS	CTRXXXXXXCGANKWS	CTRXXXXXXKNKANKWS	CTR137xxxxxWS
CRTXXXXXXKNANHWS	CTRxxxxxxFCNANHWS	CTR171XXXXXWS	CTRxxxxxxDDNANHWS	CTR195XXXXXWS
CTR196xxxxxWS	CTRXXXXXXFMNGGHWS	CTRxxxxxxFMNGGKWS	CTRXXXXXXNMNGGHWS	CTRxxxxxxKKGGHWS
CTRXXXXXXGGGHWS	CTRXXXXXXNNGGHWS	CTR245XXXXXWS	CTR256xxxxxWS	CTR259XXXXXWS
CTR263XXXXXWS	CTRxxxxxxFFKNANHWS	CTR339xxxxxWS	CTR351XXXXXWS	CTR360xxxxxWS
CTRxxxxxxWS	CTR365xxxxxWS	CTR369XXXXXWS	CTR371xxxxxWS	CTRXXXXXXFCGGSWS
CTR524xxxxxWS	CTR530XXXXXWS	CTR531xxxxxWS	CTR532XXXXXWS	CTR533XXXXXWS
CTR534XXXXXWS	CTR535XXXXXWS	CTR536XXXXXWS	CTR537xxxxxWS	CTRxxxxxxKxANHxx
CTR540xxxxxWS	CTR541xxxxxWS	PSS200008-02N	PSS200015-04N	PSS200016-05N
PSS200022-02N	PSS200077-03N	PSS200126-06N	PSS200127-06N	PSS200248-05N
PSS200423-07N	PSS200491-01N	PSS200494- 7P	PSS200685-06N	PSS200698-08N
PSS200698-09N	PSS200737-06N	PSS200826-06N	PSS200897-08N	PSS200955-04N
PSS200955-06N	PSS201038-08N	PSS201038-09N	PSS201765-03N	PSS201885-06N
PSS201885-07N	PSS202142-02N	PSS202219-01N	PSS202670-04P	PSS202979-05N
PSS202980-02N	PSS203305-09N	PSS203310-10N	PSS203402-04N	SPF203620-03C
PSS203636-04N	PSS203638-03N	INT203717-04Q	PSS203812-03N	PSS203942-03N
PSS203948-01N	PSS203951-02N	PSS204339-02N	PSS204340-04N	PSS204595-04P
INT204656-05C	INT204665-05C	PSS204735-02N	INT204837-05C	INT204885-09Z
PSS204963-05N	PSS204964-03N	PSS204973-03N	INT204977-03C	PSS204980-01N
PSS204983-02N	PSS204984-02N	PSS204985-03N	PSS204986-03N	PSS204987-02N
PSS204988-04N	PSS204990-03N	PSS204992-01N	PSS205003-03N	PSS205014-03N
PSS205037-01N	PSS205044-03N	PSS205059-03N	PSS205064-02N	PSS205070-01N
PSS205099-01N	PSS205123-05N	PSS205124-02N	PSS205129-04N	PSS205130-02N
PSS205137-01N	PSS205142-03N	PSS205185-02N	PSS205186-03N	PSS205226-05N
INT205247-03C	INT205248-01C	PSS205258-03N	PSS205259-03N	PSS205283-05N
PSS205284-02N	PSS205285-02N	PSS205288-04N	PSS205290-03N	PSS205339-03N
PSS205374-01N	PS3205376.01N	SPF205391-01C	SPF205391-02C	SPF205393-02C
SPF205394-01C	SPF205394-02C	PSS205399-01N	PSS205434-02N	PSS205477-01N
PSS205480-02N	PSS205498-03N	PSS205498-04N	PSS205504-01N	PSS205523-01N
PSS205525-02N	PSS205573-02N	PSS205576-01N	PSS205668-01N	SPF205675-01C
SPF205675-02C	SPF205675-03C	SPF205681-01C	PSS205694-02N	PSS205695-03N
SPF205722-02C	INT205773-05C	SPF205784-02C	PSS205800-02N	PSS205833-02N
PSS205855-03N	PSS205859-05P	PSS205877-00N	PSS205877-01N	PSS205926-01N
PSS205936-02N	PSS205938-00N	PSS205938-01N	PSS205968-01N	PSS205970-03N
PSS206006-01N	SPF206023-01C	PSS206039-02N	PSS206040-02N	PSS206041-02N
PSS206042-02N	PSS206043-03N	PSS206044-02N	PSS206051-03N	PSS206052-06N
PSS206053-04N	PSS206064-03N	SPF206064-04C	PSS206066-03N	PSS206067-03N
PSS206068-01N	PSS206146-01N	PSS206152-02N	INT206153-05Q	INT206154-01Q
INT206156-01Q	INT206157-01Q	PSS206170-01N	INT206182-02Z	PSS206190-01N
PSS206200-02N	PSS206205-03N	PSS206207-04N	PSS206208-03N	INT206236-01N
PSS206267-03P	PSS206267-04P	PSS206291-02P	PSS206306-01N	PSS206371-02N
PSS206371-03N	PSS206397-02N	PSS206399-01N	PSS206400-02N	PSS206405-03N
PSS206406-01N	PSS206421-02N	PSS206435-02N	PSS206436-02N	PSS206437-02N
INT206441-02C	PSS206500-02N	PSS206524-01N	PSS206572-02N	PSS206577-01N
PSS206591-00N	PSS206591-01N	PSS206592-02N	PSS206598-02N	PSS206600-02N
PSS206607-02N	INT206609-03Q	SLRC72000FWCHGW1	PSS206647-02N	PSS206653-01N
PSS206671-01N	PSS206700-01P	PSS206733-01N	SPF206734-01C	SPF206734-02C
SPF206735-01C	SPF206735-02C	SPF206736-01C	SPF206736-02C	SPF206737-01C



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

SPF206737-02C	INT206740-02C	PSS206772-02N	SLRC410002FBCJGTS	SPF206910-01C
PSS206922-00N	PSS206927-08N	PSS206928-01N	PSS206928-02N	PSS206950-00N
PSS206950-01N	PSS206967-00N	PSS206981-01N	SPF206994-00C	PSS206996-01N
SLRC320000FFCFGW1	PSS206999-04P	PSS207000-04P	PSS207008-01N	PSS207013-00N
PSS207014-02N	INT207015-03N	PSS207016-02N	PSS207016-03N	SPF207018-01C
PSS207021-02N	PSS207025-01N	PSS207025-02N	PSS207027-03N	PSS207030-00N
PSS207030-01N	PSS207032-02N	PSS207034-02N	PSS207037-00N	INT207043-03Q
INT207043-04Q	PSS207047-02N	PSS207050-03N	SPF207053-01C	PSS207058-02N
INT207064-01Z	PSS207070-00N	INT207087-00Z	PSS207095-01N	PSS207113-01N
INT207122-01Q	PSS207129-00N	PSS207129-01N	PSS207130-00N	PSS207194-02N
SPF207215-00C	INT207216-00Q	INT207217-01Q	INT207218-01Q	SPF207219-00C
PSS207220-00N	INT207221-01Q	INT207222-01Q	INT207223-00Q	INT207224-00Q
SPF207245-01C	PSS207256-02N	PSS207259-01N	INT207288-00Q	PSS207352-01N
INT207353-00Q	PSS207362-02N	INT207390-00B	INT207404-01N	PSS207405-00N
PSS207407-00N	INT207408-00Q	SPF207410-02A	SPF207417-00C	SPF207431-00C
SPF207434-00C	SPF207436-00C	SPF207437-00C	INT207444-01Q	INT207445-00Q
INT207446-00Q	INT207448-00Q	INT207449-03Q	SPF207462-00C	SPF207469-00C
SPF207471-00B	INT207485-02A	INT207490-00Q	SPF207493-00K	SPF207493-01K
PSS207496-00N	PSS207522-01N	PSS207522-02N	INT207528-00N	See
Below***	PSS207557-00N	PSS207563-01N	INT207574-01A	SPF207582-01B
SPF207593-01A	INT207596-00C	SPF207618-01C	SPF207619-00C	SPF207621-00C
SPF207622-00C	SPF207623-00C	SPF207624-00C	SPF207625-00C	SPF207626-00C
SPF207627-00C	SPF207628-00C	SPF207629-00C	SPF207631-00C	SPF207632-00C
SPF207634-00C	SPF207635-00C	SPF207636-00C	SPF207637-00C	SPF207652-00C
PSS207656-00N	INT207661-00Q	INT207662-00Q	PSS20682-00N	PSS207686-00N
PSS207686-01N	PSS207688-01N	PSS207689-02N	PSS207690-02N	PSS207691-02N
PSS207692-02N	SPF207693-00C	PSS207694-00N	PSS207695-00N	PSS207696-00N
SPF207697-00C	SPF207699-01C	SPF207700-00C	SPF207701-00C	PSS207702-00N
INT207703-00Q	PSS207705-00N	PSS207705-01N	INT207708-01A	SPF207721-01C
SPF207722-00C	SPF207725-00C	PSS207734-00N	PSS207736-00P	SPF207737-00C
PSS207740-01N	SPF207741-00C	PSS207742-01N	PSS207743-01N	PSS207744-01N
SPF207745-00C	PSS207746-02N	PSS207747-02N	SPF207748-00C	PSS207750-01N
PSS207756-01N	PSS207757-01N	PSS207758-01N	INT207760-03Q	SPF207761-00C
SPF207761-01C	SPF207762-00C	INT207769-00Q	INT207770-00Q	PSS207779-00N
PSS207794-00N	SPF207815-04C	INT207820-00N	INT207848-01Q	PSS207849-01N
PSS207850-01N	SPF207852-01A	SPF207852-02A	SPF207863-00C	PSS207864-01N
PSS207865-01N	SPF207868-00C	SPF207869-00C	INT207870-00Q	INT207871-00Q
SPF207874-00C	SFP207875-00C	SFP207876-00C	INT207880-00Q	PSS207910-00N
INT207918-03Q	INT207920-00Q	INT207921-00Q	INT207922-00Q	INT207923-00Q
INT207924-00Q	INT207925-00Q	INT207926-00Q	INT207927-00Q	INT207928-00Q
INT207928-01Q	INT207929-00Q	INT207930-00Q	INT207932-00Q	INT207934-X0Q
INT207935-X0Q	INT207936-X0Q	INT207937-X0Q	INT207955-01Q	SPF207956-00C
PSS207962-00N	PSS207963-00N	SPF207971-00C	SPF207972-00C	SPF207973-02C
PSS208001-00N	SPF208009-00C	SPF208010-00C	INT208019-00A	INT208021-02Q
SPF208023-00C	INT208028-00Q	SPF208042-01C	SPF208044-01A	PSS208048-00N
SPF208049-01A	SPF208050-01A	SPF208052-00C	SPF208053-00C	SPF208054-00C
INT208060-01C	INT208060-02C	INT208062-00A	PSS208070-00N	PSS208072-00N
SPF208073-00C	PSS208074-00N	SPF208086-00C	SPF208087-00C	PSS208088-00N
PSS208089-00N	PSS208090-00N	PSS208091-00N	PSS208092-00N	SPF208093-00C
PSS208094-00N	PSS208095-00N	SPF208096-00C	PSS208097-01N	PSS208098-00N
SPF208099-00C	PSS208100-00N	PSS208101-00C	SPF208105-00C	SPF208106-00C
SPF208107-00C	INT208108-00Q	INT208108-01Q	INT208109-00Q	INT208110-00Q
INT208110-01Q	INT208111-00Q	INT208112-00Q	INT208113-00Q	PSS208118-00N
SPF208119-00C	SPF208121-01C	INT208122-00Q	SPF208126-00C	SPF208127-00C
SPF208128-00A	PSS208146-00N	SPF208149-00C	INT208157-00Q	INT208157-01Q
PSS208162-00N	PSS208164-00N	INT208171-01Q	INT208182-00Q	PSS208183-00F



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

PSS208186-00N	PSS208187-00N	PSS208188-01N	INT208196-01Q	INT208198-02N
INT208201-00Q	INT208207-01Q	INT208209-01A	INT208228-00K	INT208228-01K
INT208229-00Q	SPF208233-00C	INT208237-01Q	INT208240-00Q	See
Below	SPF208242-00A	INT208246-00Q	SPF208251-00C	SPF208253-00A
SPF208254-01A	SPF208255-00C	PSS208264-01A	SPF208270-00C	PSS208272-00Q
PSS208273-00Q	SPF208274-00A	INT208278-02A	INT208278-03A	INT208278-04A
PSS208279-00N	SPF208290-00A	INT208291-00Q	SPF208301-00C	SPF208307-02A
PSS208315-01N	INT208317-02Q	INT208317-03Q	PSS208319-00N	INT208320-00Q
INT208321-00Q	INT208350-02A	INT208352-00Q	PSS208353-00N	PSS208359-00N
PSS208360-00N	PSS208361-01N	PSS208362-01N	SPF208364-00A	INT208365-01Q
INT208366-01Q	INT208367-01Q	INT208368-01Q	INT208369-00Q	SPF208374-00C
SPF208377-00A	SPF208377-01A	SPF208378-02A	SPF208379-00B	SPF208380-01A
SPF208380-03A	INT208384-PIZ	INT208388-00Q	INT208389-00Q	INT208391-00N
SPF208394-00C	INT208397-01Q	INT208398-01Q	INT208402-00Q	PSS208406-00N
INT208408-00Q	SPF208410-00C	INT208415-00Q	INT208415-01Q	SPF208422-00A
PSS208423-01A	INT208425-00Q	SPF208426-02A	INT208433-00A	INT208437-00Q
SPF208442-01C	INT208449-00Q	SPF208454-00C	SPF208455-00C	SPF208456-00C
INT208466-00Q	PSS208467-00N	PSS208470-00N	PSS208471-00N	SPF208474-00B
PSS208475-00A	PSS208475-02A	PSS208476-01A	PSS208476-02A	PSS208477-00B
PSS208477-01B	PSS208477-02B	INT208478-00Q	INT208478-01Q	INT208479-00Q
INT208480-00Q	PSS208482-00N	PSS208483-00N	PSS208484-00N	PSS208485-00N
PSS208486-00N	SPF208487-00C	PSS208488-00C	SPF208489-00C	PSS208490-00N
PSS208491-00N	PSS208492-00C	INT208493-00Q	INT208493-01Q	SFP208494-00C
SPF208495-00A	PSS208496-00N	SPF208497-01A	SPF208498-00A	INT208499-00Q
INT208500-00A	SPF208501-00A	SPF208502-00C	SPF208503-00A	PSS208505-00N
INT208507-PIZ	SPF208508-00C	SPF208509-00A	SPF208509-01A	SPF208512-00C
SPF208513-00A	SPF208514-00C	PSS208515-00N	PSS208515-01N	SPF208519-00A
SPF208520-00A	SPF208522-00A	SPF208523-00A	SPF208525-00A	SPF208526-PIZ
INT208527-00Q	SPF208530-00A	SPF208531-00C	INT208533-00Q	INT208534-00Q
INT208535-00N	INT208539-00Q	PSS208540-00N	PSS208541-00N	PSS208543-00N
INT208544-00Q	INT208545-00A	SPF208546-00C	INT208547-00Q	INT208548-00A
SPF208550-00C	PSS208551-00N	SPF208552-00C	INT208553-00Q	INT208554-00Q
INT208555-00Q	INT208556-00Q	INT208557-00Q	INT208558-00Q	INT208559-00Q
INT208560-00C	SPF208561-00C	SPF208562-00C	INT208563-00Q	INT208564-00Q
SPF208565-00C	INT208567-00Q	PSS208569-00A	SPF208570-00A	SPF208571-00A
INT208572-00Q	SPF208573-00C	INT208574-00Q	INT208575-00Q	INT208576-00Q
SPF208577-00C	SPF208578-00C	INT208581-00Q	SPF208583-00A	SPF208584-00A
SPF208585-00B	INT208586-00Q	INT208587-00Q	SPF208589-00A	SPF208589-01A
SPF208590-00A	INT208591-00Q	INT208594-00Q	INT208595-00Q	INT208596-00Q
SPF208598-00C	INT208599-00Q	INT208600-00C	SPF208601-00A	INT208602-00Q
INT208603-00Q	INT208604-00Q	INT208605-00Q	HVRD10043901FBCWWS	SPF208607-00C
INT208608-00Q	INT208609-00Q	INT208610-00Q	INT208611-00Q	INT208612-00Q
INT208613-00Q	INT208614-00Q	INT208615-00Q	INT208616-00Q	INT208617-00Q
INT208618-00Q	INT208619-00Q	INT208620-00C	INT208621-00C	SPF208622-00C
SPF208623-00C	SPF208625-03A	INT208626-00Q	SPF208627-00C	INT208628-00Q
INT208629-00Q	SPF208630-00C	INT208631-00Q	INT208632-00Q	INT208633-00Q
INT208634-00Q	INT208635-00Q	INT208636-00Q	PSS208637-00N	SPF208638-00C
SPF208639-00C	SPF208640-00C	SPF208641-00A	SPF208645-00C	INT208646-00Q
INT208647-00Q	SPF208649-00A	SPF208650-00A	SPF208651-00A	SPF208651-01A
SDWP208652-00Q	INT208653-00Q	INT208654-PIZ	SPF208655-00B	PSS208658-00N
INT208659-00Q	SPF208660-00A	INT208661-00Q	INT208662-00Q	INT208662-01Q
SPF208663-00A	SPF208664-00A	SPF208666-00A	INT208667-00A	PSS208668-00N
PSS208668-01N	SPF208669-00C	PSS208672-00N	PSS208672-01N	PSS208672-04N
SPF208673-00B	SPF208674-00A	SPF208674-01A	SPF208675-00A	SPF208675-01A
INT208677-00Q	INT208678-00N	SPF208679-00A	INT208683-00Q	INT208684-00Q
PSS208685-00N	PSS208686-00N	PSS208687-00N	INT208688-00N	SPF208689-00A



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

SPF208690-00A	SPF208691-00A	SPF208692-00A	SPF208693-00A	SPF208694-00A
SPF208695-00C	INT208696-00Q	INT208697-00Q	INT208698-00Q	SPF208699-00C
SPF208700-00C	SPF208701-00C	SPF208702-00C	INT208703-00Q	INT208703-01Q
INT208703-02Q	SPF208705-00A	SPF208707-00C	SDWP208708-00Q	SPF208709-00A
SPF208710-00A	INT208710-01Q	SPF208712-00A	PSS208713-00N	SPF208714-00B
INT208715-00Q	SPF208717-00C	SPF208719-00C	SPF208720-00B	SPF208721-00A
INT208722-00Q	INT208723-00Q	SPF208724-PIZ	SPF208726-00C	INT208727-00Q
PSS208728-00A	SPF208729-00A	SPF208729-01A	SPF208730-00A	PSS208732-00A
SPF208735-00C	SPF208738-00C	SDWP208739-00Q	SDWP208739-01Q	SPF208740-00C
SPF208741-00C	PSS208743-00A	INT208744-00Q	INT208744-01Q	SPF208745-00C
SPF208745-01C	SPF208746-00C	SPF208747-00C	SPF208748-00C	SPF208748-01C
SPF208749-00C	SPF208750-00C	SPF208751-00C	SPF208752-00C	SPF208753-00C
SPF208754-00A	INT208755-00Q	SDWP208756-00Q	SDWP208757-00Q	PIZ8758
SDWP208759-00Q	SDWP208760-00Q	SPF208761-00A	SDWP208762-00Q	INT208763-00Q
INT208763-01Q	SPF208764-00C	SPF208765-00A	SDWP208766-00Q	SDWP208766-01Q
SPF208767-00C	SPF208768-00C	PSS208769-00N	PSS208770-00N	INT208771-00Q
SPF208773-00C	PIZ8774	SPF208775-00C	SPF208776-00B	INT208777-00Q
INT208778-00Q	SDWP208781-00Q	SDWP208782-00Q	SPF208784-00A	INT208785-00Q
INT208786-00Q	INT208787-00Q	SPF208788-00A	INT208789-00Q	INT208790-00Q
INT208791-00Q	INT208792-00Q	INT208793-00Q	INT208794-00Q	INT208795-00Q
INT208796-00Q	INT208797-00Q	INT208798-00Q	INT208799-00Q	INT208800-00Q
INT208801-00Q	INT208802-00Q	INT208803-00Q	INT208804-00Q	SPF208806-00A
PSS208807-00N	SPF208808-00C	SPF208808-01C	SPF208809-00C	INT208810-00Q
SPF208811-00A	SPF208812-00B	PSS208813-00N	PSS208813-01N	PSS208814-00N
SPF208815-00A	SPF208816-00A	INT208817-00Q	PSS208818-00N	INT208819-00Q
INT208820-00Q	INT208821-00Q	INT208822-00Q	INT208823-00Q	INT208824-00Q
INT208825-00Q	INT208826-00Q	INT208827-00Q	INT208830-00Q	INT208831-00Q
PSS208833-00A	INT208835-00Q	SPF208837-00B	PSS208838-00A	SPF208839-00C
INT208840-00Q	INT208841-00Q	INT208842-00Q	INT208843-00Q	INT208844-00Q
INT208845-00Q	INT208846-00Q	PSS208848-00N	PSS208850-00N	PSS208850-01N
PSS208851-00A	PSS208852-00N	PSS208852-01N	PSS208853-00A	SPF208854-00C
PSS208855-00N	PSS208855-01N	SPF208856-00B	SPF208857-00A	INT208858-00Q
INT208858-01Q	PSS208859-00N	PSS208861-00N	PSS208862-00N	SPF208863-00A
SPF208865-00A	INT208866-00A	PIZ8867	SDWP208868-00C	SDWP208869-00C
INT208870-00Q	INT208871-00Q	PSS208873-00N	PSS208874-00N	PSS208875-00N
PSS208876-00N	PSS208877-00N	PSS208878-00N	PSS208879-00N	PSS208880-00N
SPF208881-00A	INT208882-00Q	PIZ8883	PIZ8884	PSS208886-00A
PSS208887-00A	INT208888-00Q	INT208888-01Q	SPF208889-00C	INT208890-00Q
INT208891-00Q	INT208892-00Q	INT208893-00Q	PSS208894-00A	PSS208897-00N
PSS208897-01N	PSS208900-00A	INT208901-00Q	INT208902-00Q	SPF208903-00A
PSS208905-00N	PSS208905-01N	SPF208906-00C	SPF208907-00C	SPF208907-01C
SPF208908-00A	SPF208909-00A	SPF208910-00A	SPF208911-00A	PSS208912-00N
SPF208913-00A	SPF208917-00A	SPF208918-00A	SPF208919-00C	SDWP208920-00Q
INT208921-00Q	INT208922-00Q	SPF208923-00A	SPF208925-00A	SPF208926-00A
PSS208927-00N	INT208928-00Q	SPF208933-00B	PSS208934-00N	PSS208935-00N
PSS208936-00N	PSS208937-00N	PSS208937-01N	SPF208938-00C	PSS208939-00N
SPF208940-00A	SPF208940-02A	PSS208941-00N	PSS208942-00A	PSS208943-00A
SDWP208944-00Q	SDWP208944-01Q	SPF208946-00C	SPF208947-00C	SPF208948-00C
SPF208949-00C	SPF208950-00C	SPF208951-00C	SPF208952-00C	SPF208953-00C
INT208954-00Q	SDWP208958-00Q	INT208959-00Q	INT208960-00Q	INT208960-01Q
SPF208961-00A	INT208965-00Q	INT208966-00Q	INT208966-01Q	INT208967-00Q
INT208967-01Q	INT208968-00Q	INT208968-01Q	INT208969-00Q	INT208969-01Q
INT208969-02Q	INT208970-00Q	INT208970-01Q	INT208971-00Q	INT208971-01Q
INT208972-00Q	INT208972-01Q	INT208973-00Q	INT208973-01Q	INT208974-00Q
INT208974-01Q	INT208975-PIZ	INT208976-PIZ	INT208977-PIZ	INT208978-PIZ
SPF208979-00A	SPF208984-00A	INT208986-00Q	INT208987-00Q	PSS208988-00N



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

PSS208989-00N	PSS208990-00N	PSS208991-00N	PSS208992-00N	SPF208995-00A
SPF208995-01A	INT208996-00Q	SLRC810002FFEFTWS	SPF209000-00C	SPF209001-00C
INT209003-00Q	SPF209005-00C	SPF209009-00C	SPF209014-00B	PSS209015-00N
PSS209015-01N	SPF209017-00A	SPF209019-00C	SPF209022-00A	SPF209023-00A
INT209024-00Q	SPF209026-00A	see	note	PSS209033-00N
PSS209034-00N	PSS209035-00N	INT209036-00Q	INT209037-00Q	PSS209039-00N
PSS209040-00N	SPF209042-00C	INT209043-00B	INT209043-01B	PSS209044-00N
PSS209044-01N	PSS209045-00N	SPF209046-00C	SPF209047-00C	INT209048-00Q
SPF209049-00A	INT209050-00B	INT209050-01B	PSS209051-00N	SPF209052-00C
SPF209053-00C	INT209054-00Q	SPF209056-00A	INT209057-00Q	SPF209058-00A
SPF209059-00A	SPF209060-00A	SPF209061-00C	INT209065-00Q	SPF209067-00A
SPF209068-00A	SPF209069-00A	INT209070-00Q	INT209072-00Q	INT209073-00Q
INT209074-00B	INT209075-00B	SPF209076-00A	SDWP209077-00Q	PSS209078-00N
SPF209079-00C	INT209082-00Q	PSS209083-00	SPF209084-00C	PSS209085-00N
PSS209086-00N	PSS209087-00A	PSS209088-00A	INT209092-00C	SPF209093-00C
SDWP209094-00Q	INT209095-00B	INT209095-01B	INT209096-00B	SDWP209097-00Q
SPF209098-00A	INT209100-00B	INT209101-00B	PSS209102-00N	INT209103-00B
INT209104-00B	INT209105-00Q	INT209105-01Q	SPF209106-00A	INT209107-00Q
INT209108-00Q	SPF209109-00C	INT209110-00Q	INT209111-00Q	INT209112-00Q
INT209114-00Q	SPF209115-00C	PSS209116-00N	PSS209117-00N	INT209119-00Q
SPF209195-00A	PSS209120-00N	INT209121-00Q	PSS209127-00N	PSS209128-00N
PSS209129-00N	PSS209130-00N	PSS209131-00N	PSS209132-00N	PSS209133-00N
PSS209134-00N	PSS209135-00N	SPF209136-00C	INT209138-00Q	INT209141-00C
PSS209142-00N	INT209143-00Q	SPF209144-00C	SPF209145-00C	SPF209146-00C
SPF209147-00C	SPF209148-00C	SPF209149-00C	SPF209150-00C	SPF209151-00C
SPF209152-00C	SPF209153-00C	SPF209154-00C	SPF209155-00C	SPF209156-00C
SPF209157-00C	SPF209158-00C	SPF209159-00C	SPF209160-00C	INT209162-00Q
INT209163-00Q	SPF209164-00C	PSS209173-00N	INT209175-00Q	INT209176-00Q
INT209179-00Q	SPF209184-X0C	SPF209185-X0C	SPF209186-X0C	SPF209188-00A
SPF209189-00A	INT209190-00Q	SPF209191-00A	INT209193-00Q	SDWP209194-00Q
PSS209196-00N	SPF209197-00C	SPF209198-00C	SPF209199-00C	SPF209200-00A
SPF209201-00A	SPF209202-00A	SPF209204-00A	SPF209205-00A	SPF209206-00A
INT209207-00Q	INT209208-00Q	SPF209209-00A	SPF209210-00A	SPF209211-00A
SDWP209212-00A	SDWP209213-00A	INT209214-00Q	INT209215-00Q	INT209216-00Q
SFP209218-00A	INT209219-00A	INT209220-00B	PSS209223-00N	PSS209224-00N
PSS209225-00N	PSS209226-00N	PSS209227-00N	PSS209228-00N	INT209229-00Q
INT209230-00Q	PSS209231-00N	SPF209233-00A	SPF209234-00A	PSS209237-00N
SPF209238-00A	SPF209239-00A	INT209240-00Q	INT209241-00Q	SPF209242-00C
SPF209243-00A	INT209244-00Q	SPF209246-00A	SPF209247-*0A	SPF209248-*0A
SPF209249-00A	SPF209250-00A	SDWP209251-00Q	SPF209253-00A	INT209254-00Q
INT209255-00B	PSS209256-00N	SDWP209257-00Q	INT209258-00Q	INT209259-00Q
SPF209260-00A	PSS209261-00N	SDWP209262-00Q	PSS209263-00N	INT209265-00Q
PSS209266-00N	PSS209267-00N	SPF209269-00A	INT209270-00Q	INT209271-00Q
INT209272-00Q	SPF209273-00Q	INT209274-00Q	SPF209275-00C	INT209276-00A
INT209277-00B	INT209278-00B	INT209279-00B	INT209281-00Q	SPF209282-00A
INT209283-00Q	SPF209284-00A	INT209285-00Q	INT209286-00Q	INT209287-00Q
INT209288-00Q	INT209289-00Q	PSS209291-00N	PSS209292-00N	INT209293-00Q
INT209295-00Q	SPF209297-00A	SPF209298-00A	SPF209299-00Q	SPF209300-00C
SPF209301-00A	PSS209302-00N	INT209303-00Q	INT209304-00Q	SPF209305-X0A
INT209306-00Q	INT209307-00Q	INT209308-00Q	INT209309-00Q	INT209310-00Q
INT209311-00Q	INT209312-00Q	INT209313-00Q	INT209314-00Q	INT209315-00Q
INT209316-00Q	INT209317-00Q	INT209318-00Q	INT209319-00Q	INT209320-00Q
INT209321-00Q	INT209322-00Q	INT209323-00Q	SDWP209324-00Q	INT209344-00Q
INT209345-00Q	INT209346-00Q	INT209347-00Q	INT209348-00Q	INT209349-00Q
INT209350-00Q	INT209351-00Q	INT209352-00Q	INT209353-00Q	INT209354-00Q
INT209355-00Q	INT209356-00Q	INT209357-00Q	INT209358-00Q	INT209359-00Q



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

INT209360-00Q	INT209361-00Q	INT209362-00Q	INT209363-00Q	INT209364-00Q
INT209365-00Q	INT209366-00Q	INT209367-00Q	INT209368-00Q	INT209369-00Q
INT209370-00Q	INT209371-00C	INT209372-00Q	INT209373-00Q	INT209374-00Q
INT209375-00Q	PSS209376-00N	INT209377-00C	INT209378-00C	SPF209379-00C
INT209380-00Q	INT209380-01Q	INT209382-00Q	SPF209383-00A	SPF209384-00A
SPF209385-00A	INT209386-00Q	SPF209387-00C	INT209388-00Q	INT209389-00N
INT209390-00Q	INT209390-01Q	SDWP209391-00Q	INT209392-00Q	SPF209393-00A
INT209394-00Q	SPF209395-00A	INT209396-00Q	INT20397-00Q	SDWP209398-00Q
PSS209399-00A	INT209400-00Q	SPF209401-00C	SPF209402-X0A	SPF209403-00A
SPF209404-X0A	SPF209405-00C	SPF209406-X0A	SPF209407-X0A	PSS209408-00A
INT209409-00Q	INT209410-00Q	INT209411-00Q	INT209412-00Q	SPF209413-00C
PSS209414-00A	PSS209415-00A	INT209416-00Q	INT209417-00Q	INT209418-00Q
INT209419-00Q	INT209420-00Q	INT209421-00Q	PSS209422-00A	PSS209423-00A
INT209425-00N	INT209426-00C	INT209427-00C	INT209428-00C	SDWP209429-00Q
PSS209430-00N	SDWP209433-00Q	SPF209436-00A	SPF209437-00A	SDWP209438-00Q
SDWP209439-00Q	SPF209440-00C	SDWP209441-00Q	SPF209442-X0C	SPF209443-X0C
SPF209453-00A	PSS209454-00N	PSS209455-00N	SPF209456-00A	PSS209457-00N
PSS209458-00N	PSS209459-00N	INT209460-00Q	INT209463-00Q	INT209464-00Q
INT209465-00Q	INT209466-00Q	INT209467-00Q	PSS209468-00A	INT209469-00Q
INT209470-00Q	SDWP209472-00Q	INT209473-00Q	INT209474-00Q	INT209475-00Q
SPF209476-00C	INT209477-00Q	SPF209480-00C	SDWP209481-00Q	SDWP209482-00Q
SDWP209483-00Q	INT209485-00Q	INT209486-00Q	INT209487-00Q	INT209492-00Q
PSS209493-00A	INT209494-00Q	INT209495-00Q	PSS209496-00A	PSS209497-00A
PSS209498-00A	SPF209499-00A	SPF209500-00C	PSS209502-00N	PSS209506-00A
INT209507-00Q	SPF209508-00C	INT209509-00Q	SPF209510-00A	SDWP209511-00Q
PSS209511-01N	SDWP209512-00Q	SDWP209513-00Q	PSS209514-00N	SPF209515-X0A
INT209516-00Q	SPF209520-00C	SPF209521-00A	SPF209522-00A	SPF209523-00A
SPF209524-00A	SPF209525-00A	SPF209527-00A	SPF209528-00A	SPF209529-00A
PSS209532-00N	SPF209533-00A	SPF209534-00A	PSS209538-00N	PSS209539-00N
PSS209540-00A	PSS2094541-00N	PSS2094542-00N	SPF209543-00A	PSS209544-00N
PSS209545-00N	PSS209546-00N	PSS209547-00N	PSS209548-00A	SPF209549-00C
PSS209550-00N	SPF209551-00A	SDWP209553-00Q	PSS209554-00A	PSS209555-00A
PSS209556-00A	PSS209557-00A	PSS209558-00A	PSS209559-00A	SLRN410002BACJTWS
SPF1AP03041N11W1	SPF209562-00A	PSS209563-00N	SDWP209564-00Q	BCRXXXXXXMAHWS
BCR012xxxxxWS	BCR01627000JWS	BCR43200FKAHWS	BCR054xxxxxWS	BCRxxxxxxxxxWS
BCRxxxxxWS	BCRxxxxxKAHWS	BCRxxxxxWS	BCRxxxxxCGHWS	BCRxxxxxEGHWS
BCRXXXXXCGSWS	BCR306xxxxxWS	BCR307xxxxxWS	BCR310xxxxxWS	BCR311xxxxxWS
BCR313xxxxxWS	BCR314xxxxxWS	SFMxxxxxEAGKWS	SFMxxxxXCGGHWS	SFMXXXXXXRGGHWS
SFMxxxxxCANHxx	SFMxxxxxKGNHWS	SFMXXXXXXWS	SFMxxxxxKGGHyy	SFM091XXXXXXWS
SFM0971000BFWS	SFMXXXXXXMAGKWS	SFM118XXXXXXWS	SFMXXXXXXKANKWS	SFM130XXXXXXWS
SFM133XXXXXXWS	SFM48700FEANSWS	SFMxxxxxKANSWS	SFM184XXXXXXWS	SFM185XXXXXXWS
SFM186XXXXXXWS	SFM187XXXXXXWS	SFM188XXXXXXWS	SFM189XXXXXXWS	SFM190XXXXXXWS
SFM226xxxxxWS	SFM237XXXXXXWS	SFMxxxxxKGGKWS	SFM266XXXXXXWS	SFM267XXXXXXWS
SFMXXXXXEKNKWS	SFMXXXXXRGNHWS	SFMxxxxxMAGHWS	SFMxxxxxKGGHDW	SFM276XXXXXXWS
SFM277xxxxxWS	SFM306XXXXXXWS	SFM311XXXXXXWS	SFM312XXXXXXWS	SFM316XXXXXXWS
SFM317XXXXXXWS	SFM318xxxxxWS	SFM323XXXXXXWS	SFM324xxxxxWS	SFM328xxxxxWS
SFM329xxxxxDW	SFMXXXXXKGNHFW	SFMXXXXXEANHWT	SFMxxxxxKGNKWS	SFM266XXXXXXCS
SFXXXXXX4MANHWS	SFXXXXXXHWS	SFXXXXXX4EANHWS	SFXXXXXX4EANKWS	SFxxxxxK3ANHWS
SFxxxxxM3ANHWS	SFX079XXX3KWS	SFXXXXXXK4ANPWS	SFXXXXXXM4ANPWS	WSFX106XXX3F
WSFX107XXX3F	SFxxxxxM3ANKWS	SFX13210003FWS	WSFX151XXX4J	SFxxxxxC4ANKWS
SFxxxxxM4ANKWS	SFX161xxxxFWS	SFXXXXXXM3GGHWS	SFX215XXXXXXWS	SFXXXXXXW4GNKWS
SFXXXXXXC3GNHWS	SFX311XXXXXXWS	SFCXXXXXMSGHWS	SFCXXXXXMSGNKWS	SFCXXXXXMSGKWS
SFPXXXXFKANH	SFPXXXXCANHWS	SFPXXXXEANHWS	SFN011XXXXXXWS	SFNXXXXKGNHWS
SFNxxxxxBGNHWS	SFN208XXXXXXWS	SFNxxxxxBGNKWS	QFMxxxxxGNHWS	QFMxxxxxKGNHWS
QFNxxxxFCGNHWS	QFNxxxxKGNHWS	QFNxxxxEGNHWS	QFNxxxxMGNHWS	QFX024xxxxFWS
QFX025xxxxFWS	QFXXXXXXXXNKWS	NCAA006XXXXXXWS	CBBXXXXAHWS	CBCxxxxAHWS



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

CBCXXXXXXGHWS	NCxxxxxxxMAKWS	NCXxxxxxxxNGKWS	CBA056XXXXXKWS	CMX086XXXXXWS
CBA1101500BKWS	NCXxxxxxxxMGHWS	CBAXXXXXXGKWS	CBB3100BKGKWS	CBC9300BKGKWS
NCXxxxxxxxNGHWS	CMN-011-0012WS	CMN-013-0019WS	CMN0140019WS	CMN-012-0069WS
CMN-011-0070WS	CMN-011-0071WS	CMN-011-0081WS	CMN-011-0082WS	CMN-011-0083WS
CMN-012-0083WS	BRCPAxxxxxGCWS	BRCPBxxxxxGCWS	BRCPAKIT01	BRCPBKIT01
CTAXXXXXXXHWS	CTTXXXXXDEGANHWS	RCN-012-0010WS	RCN-011-0011WS	RCN0150015WS
RCN-011-0016WS	RCN-011-0038WS	RCN-011-0039WS	RCN-012-0039WS	RCN-013-0039WS
RCN-011-0043WS	RCN0110044WS	RCN0120044WS	RCN0130044WS	RCN0110045WS
RCN0120045WS	RCN0130045WS	RCN0110046WS	WMIGN100xxxxxK	MICXXXXXXMGNHWS
MICXXXXXXKMGKWS	MICXXXXXLMGGHWS	MICXXXXXXKSGGKWS	MICXXXXXESGGKWS	MICXXXXXKMGNKWS
MICXXXXXXMGGHWS	MICXXXXXLSGNHWS	MICxxxxxCMGNKWS	MICxxxxxKMSNHWS	MICXXXXXXKSSNHWS
MICXXXXXXMGNHTS	MIC203xxxxxWS	MIC204xxxxxWS	MICXXXXXLMGNHT5	MICXXXXXXKMSNHT5
MICXXXXXLMGNHTF	MICXXXXXXKMSNHTF	MIC5000BFRMENHWS	MICXXXXXRMEWHT5	TMRXXXXXXNHWS
TMR005xxxxxWS	TMR007xxxxxWS	TMR010xxxxxKWS	TMR011xxxxxKWS	TMR016xxxxxKWS
TMR0172400AKWS	TMRXXXXXKNHWS	TMR100xxxxxKWS	TMRxxxxxKNHT5	TMR3055600AJWS
MIBxxxxxKMGNHWS	MIBxxxxxKSGNHWS	MIBXXXXXKMGHWS	MIBxxxxxLMGNHWS	MIBXXXXXKSGGHWS
MIBXXXXXKMGNHT5	MIFXXXXFKMGNHWS	MIFXXXXGKMGNKWS	MIFXXXXXKMGNHT5	SSUB0110011FW
SSUB0110028WS	SSUB0120028WS	SSUB0110064W1	SSUB0110068W1	SSUB0110069W1
SSUB0110070W1	SSUB0110071W1	SSUB0110072W1	SSUB0110073W1	SSUB0110074W1
SSUB0110075W1	SSUB0110076W1	SSUB0110077W1	SSUB0110078W1	SSUB0110080W1
SSUB0110081W1	SSUB0110082W1	MSFMxxxxxEANHy	MSFMxxxxxKANHy	MSFMxxxxxMANHWS
MSFMXXXXXEGNHWS	MSFMxxxxxCGNHyy	MSFMXXXXXKGNHWS	MSFMXXXXXMGNHWS	MSFMXXXXXKGGHWS
MSFMxxxxxEGGHWS	MSFM300XXXXXWS	MSFM301XXXXXJWS	IGBRAXXXXXMPHWS	IGBRAXXXXXJPCWS
IGBRAXXXXXJPHWS	IGBRAXXXXXJTHWS	IGBRBxxxxxAPHWS	IGBRBxxxxxAPCT5	IGBRBxxxxxANCT5
IGBRBxxxxxJPHWS	IGBRBxxxxxOPCWS	IGBRBxxxxxJPCyy	IGBRBxxxxxAPCWS	IGBRBxxxxxANCWS
IGBRBxxxxxANHWS	IGBRBxxxxxJNHWS	IGBRCxxxxxJPHWS	IGBRCxxxxxAPHYY	IGBRCxxxxxJNCyy
IGBRCxxxxxJPCyy	IGBRCxxxxxAPCY	IGBRCxxxxxOPCWS	IGBRCxxxxxJNHWS	IGBRCxxxxxMNCWS
IGBRCxxxxxMPCWS	IGBRCxxxxxOPHWS	IGBRCxxxxxONHWS	IGBRCxxxxxANCT5	IGBRCxxxxxAPCT5
IGBRCxxxxxJNCT5	IGBRCxxxxxJPCT5	IGBRCxxxxxONCyy	IGBRCxxxxxJNCTF	IGBRCxxxxxJNCTS
IGBRCxxxxxJPCTS	IGBRCxxxxxJTCWS	IGBRDxxxxxWNKWS	IGBRDxxxxxWPCWS	IGBRDxxxxxOPHWS
IGBRDxxxxxONHWS	IGBRDxxxxxWPHWS	IGBRDxxxxxWNHWS	IGBRDxxxxxJPHWS	IGBRDxxxxxJPCyy
IGBRDxxxxxANCyy	IGBRDxxxxxAPCT5	IGBRDxxxxxJNCT5	IGBRDxxxxxJPCT5	IGBRDxxxxxWNCT5
IGBRDxxxxxWPCT5	IGBRDxxxxxONCT5	IGBRDxxxxxOPCT5	IGBRDxxxxxONCWS	IGBRDxxxxxJNCWS
IGBRDxxxxxWNCWS	IGBRDxxxxxJNCTF	IGBRDxxxxxMNCWS	HFWPAAxxxxxVMNHWS	HFWPABxxxxxVMNHWS
HFWPACxxxxxVMNHWS	HFWPADxxxxxVMNHWS	HFWPNAxxxxxVMNHWS	HFWPNBxxxxxVMNHWS	HFWPNCxxxxxVMNHWS
HFWPBAxxxxxVMNHWS	HFWPBBxxxxxVMNHWS	HFWPBCxxxxxVMNHWS	CB3-002XXXXXWS	CC1-XXXXXXKSSNHWS
CC2-xxxxxKSGNHWS	CC3XXXXXCSSNHWS	CC3-xxxxxKSGNHWS	CC3-110XXXXXGWS	CC3-XXXXXBESANHWS
CC4XXXXXCSSNHWS	CC4-xxxxxCESNHWS	CC4-xxxxxCETNHWS	CC5-XXXXXEESGGHWS	CC6xxxxxKSGNHWS
CC7129XXXXXWS	CC7130XXXXXWS	CC7204xxxxxBWS	CC7206XXXXXWS	CC721115901FWS
CC721411301GWS	CC8-XXXXXESGNHWS	CC8-XXXXXCNGNHWS	CC8-206XXXXXBWS	CC8-207XXXXXBWS
CC8-XXXXXCSSGGHWS	CC8-XXXXXCNGGHWS	CC8-XXXXXKSGGHWS	CC8-XXXXXKSAGHWS	CC8-XXXXXCSSGNHWS
CCB01747500FWS	CCB05110701FWS	CCB05210701FWS	CCB05310201FWS	CCB05410201FWS
CCB05510001GWS	CCB0576490GWS	CCB05824900GWS	CCB060XXXXXGWS	CCB06210001GWS
CCB06310001GWS	CCB111xxxxxWS	CCB113xxxxxWS	CCB12343751BWS	CCB13212000JWS
CCB13328500JWS	IGBR20101000D	EWR2027-00C	EWR2096	EWR2126
EWR2136	EWR2147	EWR2151	EWR2155	EWR2167
EWR2203	EWR2242	EWR2258	EWR2261-00N	EWR2286
EWR2340	EWR2340-00N	EWR2387	EWR2406	EWR2419
EWR2482	EWR2487	EWR2496-00N	EWR2502	EWR2524
EWR2541	EWR2548	EWR2558-PIZ	EWR2570	EWR2585
EWR2593	EWR2603-00N	EWR2603-01N	EWR2720	EWR2720-00N
EWR2738-00Q	EWR2758	EWR2760	EWR2761	EWR2783
EWR2803	EWR2804	EWR2807	EWR2927	EWR2941
EWR2943	EWR2946	EWR3069	EWR3199	EWR3243
EWR3437	EWR3441	EWR3476	EWR3502	EWR3520
HVRDxxxxxxxxxyCWTS	HVRDxxxxxxxxxyCWWS	PIZ3320	PIZ3322	PSCXXXXX4A1GNHW1



# Product Change Notification



Product Group: TF/Tuesday April 21, 2026/PCN-TF-001-2026-REV-0

The DNA of tech.™

RFCS0402XXXXXXCT1	RFCS0402xxxxxxGFW	RFCS0402xxxxxxGT1	RFCS0402xxxxxxGWS	RFCS0402XXXXXXTWS
RFCS1003xxxxxxGWS	RFLW3NXXXXXXNWS	RFLW3N3000BXNT5	RFLW3N3000BXNWS	RFLW3P1500BMSWS
RFLW5NXXXXXXNWS	BCR86400BEGHWS			

**Vishay EFI**  
**ENGINEERING**  
**TECHNICAL REPORT**



**DESCRIPTION:** Waffle Pack Insert Alternative Evaluation

**PROCESS CHANGES  
REQUIRED:**

**REQUESTED BY:** Purchasing/Quality

**REPORT NO.:** 2026-0008

**REFERENCE:** PI 200-006

**ATTACHMENTS:**

---

**DISTRIBUTION:** NA

---

<b>ANALYST</b>	<b>DATE REPORTED</b>	<b>APPROVAL</b>
Mark Curtice	April 10, 2026	

---

*Vishay EFI*  
111 Gilbane St., Warwick, RI 02886

**\*\*\* CONFIDENTIAL PROPERTY OF Vishay EFI \*\*\***

**Description:**

Vishay EFI uses 1.75"x1.75" Tyvek sheets as part of packaging devices into 2"x2" waffle packs. Recently, Entegris has extended the lead time for these Tyvek sheets from 2-3 weeks to over 30 weeks. The search for an alternate vendor has not identified an available source for the Tyvek sheets. Entegris offers alternate material (IDPE – inherently dissipative polyethelene) sheets to perform the same function that are available for immediate order. This report documents a comparison of the sheets and an evaluation of these new sheets to use as a backup option.

**Activity / Analysis:**

The specifications for the Tyvek and IDPE were compared from the Entegris website. The datasheet comparison is shown in Table 1.

Part Number	Static Decay Time (sec.)	Surface Resistivity (ohm/sq.)	Color	Thickness	Material
H20-001D	1.5 - 2.0	10 <sup>5</sup> - 10 <sup>12</sup>	White	0.002" - 0.010" (0.05 mm - 0.26 mm)	Tyvek®
H20-001-0715	1.5 - 2.0	10 <sup>6</sup> - 10 <sup>10</sup>	Opaque	0.008" ±0.001" (0.20 mm ±0.03 mm)	IDPE (inherently dissipative polyethylene)

Table 1 – Datasheet comparison between sheets

Review of the datasheet shows that both materials have the same dimensional and ESD static control specifications. The IDPE has a tighter thickness tolerance which is within the Tyvek tolerance. There is a visual difference between the sheets.

A pack of the IDPE sheets were obtained for evaluation. The sheets were placed into waffle packs with 0.015"x0.015" parts, 0.020"x0.020" parts, and 0.040"x0.040" parts. The waffle packs were shaken to simulate excessive handling of the parts in the waffle packs. The waffle packs were reopened and inspected for movement of the inside parts. A handful of parts were found to have moved, but the frequency was the same as waffle packs with Tyvek sheets. One significant observation was made regarding the orientation of the IDPE sheets. The IDPE sheets have a rough side and a smooth side. The smooth side needs to be placed towards the parts to prevent any sticking of the parts to the sheet.

**Conclusion:**

This report documents the comparison of standard Tvek sheets to alternate IDPE sheets for packing parts in a waffle pack. This evaluation shows matching performance of the two sheets. We will allow the use of the IDPE sheets as a back up when the Tyvek sheets are not available.

Vishay Material Code	Customer Material	Location
SPF205681-01C	VCS3440-0005 REV:D	Ft Worth
SPF205722-02C	VCS3440-0006 REV:A	Ft Worth
PSS207025-02N	STC40017 REV:A (10072-RN1)	Ft Worth
SPF207761-01C	VCS210-007-001 REV:C	Ft Worth
SPF207437-00C	VCS8080004536-1 REV:A	Ft Worth
SPF207434-00C	VCS8080004539-1 REV:B	Ft Worth
PSS208852-01N	VCS9C7214-1 REV:B	Ft Worth
PSS209237-00N	VCS9C8376-1 REV:1	Ft Worth
PSS209544-00N	SCD-010109-001 REV:B	Ft Worth
PSS209545-00N	SCD-010109-002 REV:B	Ft Worth
PSS209546-00N	SCD-010109-003 REV:B	Ft Worth
PSS209547-00N	SCD-010110-001 REV:A	Ft Worth
EWR3069	VCS13440192-3 REV:A	Ft Worth
SLRC32000FFCFGW1	VTFSLRC32000FFCFGW1	Maisach Gernlinden